

# INSTALLATION INSTRUCTIONS

## Dodge Ram Dash Pods

### Models 15001 & 15002



1. Remove the center dash screw located along the front edge of the dash by the windshield.
2. Install the gauges in the Dash Pod (Leaving the center gauge out to allow tightening of the bracket).
3. Install dash pod on the dash in the correct position, making sure aluminum bracket is in the correct position to reinstall the center dash screw.

*NOTE: Due to inconsistencies in the dash from vehicle to vehicle, slight sanding of the dash pod and /or shortening of the aluminum mounting bracket may be required to achieve a perfect fit. When the center dash screw is tightened, this will also pull down on the pod to help create a clean fit.*

4. Run gauge wiring choosing one of the two following options:  
Option 1: Run wiring along the base of windshield, down the driver side kick-panel, and out through the firewall.

Option 2: Make a small hole in the dash under the Dash Pod, run wiring down and out through the firewall.

*NOTE: Installing this dash pod with mechanical pressure gauges may require 12 ft. nylon tubing kit model 3226 (not for use with fuel pressure gauges). 12 ft. capillary tubing may also be needed on mechanical temperature gauges.*

5. Retighten dash screw. Model 15002 requires a one inch spacer and screw (provided) between the dash and bracket.
6. Install center gauge.

#### NOTE

Due to normal manufacturing processes you may have "flashing" (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the "flashing."

### Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.

FOR SERVICE CONTACT: AUTO METER PRODUCTS Inc. 413 W. Elm St., Sycamore, IL 60178 USA (815) 895-8141 or  
Email us at [service@autometer.com](mailto:service@autometer.com)